




# AIO 2400 APP Guide

2023/12/28

We envision being a Clean EnergyTech platform that sustains communities and families.

## Step 1: Turn on your AIO 2400



Step1 Turn on  
your AIO 2400

1. Press and hold the power button.
2. Continue holding the power button down until you hear a beep sound.
3. After you hear the beep, release the power button.
4. You will see the green light start flashing.
5. Keep waiting, once the green light stops blinking and stays on steadily, this means the device has successfully powered on.

For a visual demonstration of turning on the device and the light sequence, please refer to the accompanying video.

**Step 2:** Download the APP installation package (for Android)

**Step 3:** Add Device, choose **AIO 2400**






com.zendure.iot-202312151  
13634-4.7.5-...le-release.apk





[APK Download Link](#)



Open Zendure APP






## Step 4: Wi-Fi Network settings






## Step 5: Initialization Setup

Select the microinverter model and set the power output from the AIO to the home



## Step 6: Firmware update



- Update the firmware, make sure that the version number of the Master firmware is **V1.0.13** and the version number of the BMS firmware is **V1.0.4**.
- If the firmware version is not updated, please contact us.